












	Original	Replacement	Original	Replacement
	Power		Power	
	Play		Play	
	Pause		Pause	
	Stop		Stop	
	Skip/Search +		>>	
	Skip/Search-		<<	
	Repeat		Text	
	CD Display		Info	
	Volume+		Vol +	
	Volume-		Vol -	
	Mute		Mute	

