







































































Original		Replacement		Original		Replacement	
	Power		Power		EPG / Page +		Guide
	Mute		Mute		EPG / Page +		>>
	Menu		Menu		1 / Fav A / Red		1
	Exit		Exit		1 / Fav A / Red		Red
	Up / CH +		Up		2 / Fav B / Green		2
	Up / CH +		Ch +		2 / Fav B / Green		Green
	Down / CH -		Down		3		3
	Down / CH -		Ch -		4 / Fav C / Yellow		4
	Right / V +		Right		4 / Fav C / Yellow		Yellow
	Right / V +		Vol +		5 / Fav D / Blue		5
	Left / V -		Left		5 / Fav D / Blue		Blue
	Left / V -		Vol -		6		6
	OK		Ok		7		7
	TV / Radio		TV/R		8		8
	CH List		List		9		9
	Recent CH / Page		Pre Ch		0		0
	Recent CH / Page		I<<		Sound Track		Dual



