





























































Original	Replacement	Original	Replacement
	Power		Power
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	<		<< / Preset-
	Pause		Pause / Step / Freeze
	>		>> / Preset+
	Info		Info / Angle
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	Titles		Subtitle / EQ
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
			Left
			Up
			Right
			CH+ / Page+
			OK
			CH- / Page-
			Down
			Smart / List
			Back / Return
			Guide / EPG / -/--
			1
			2
			3
			4
			5
			6
			7





Original	Replacement	Original	Replacement
 8	 8		
 9	 9		
 0	 0		
 PVR	 Display / Media		
 Page Up	 Shift + CH + /		
 Page Down	 Shift + CH - /		

