



| Original | Replacement | Original | Replacement |
|---|--|---|---|
|  Power |  Power |  Vol- |  Vol- |
|  1 |  1 |  OK |  OK |
|  2 |  2 |  Down |  Down |
|  3 |  3 |  P- |  CH- / Page- |
|  4 |  4 |  i |  Info / Angle |
|  5 |  5 |  CL |  D.Menu / Top |
|  6 |  6 |  Mute |  Mute / Dimmer |
|  7 |  7 |  TXT |  Text / Goto |
|  8 |  8 |  Red |  Red / Netflix / Search |
|  9 |  9 |  Rec |  Rec / Rec Mode |
|  0 |  0 |  Green |  Green / APP / Repeat |
|  0 |  AV / Input / RDS |  Timer |  Sleep / Timer |
|  Up |  Up |  Yellow |  Yellow / YouTube / Repeat |
|  P+ |  CH+ / Page+ |  Picture |  Picture / Format |
|  Right |  Right |  Blue |  Blue / Prime Video / Random |
|  Vol+ |  Vol+ |  Sound |  Sound / Title |
|  Left |  Left |  (I)- |  Shift + CH- / Page- |



