



Original	Replacement	Original	Replacement
 Power	 Power	 Vol +	 Vol +
 Source	 AV	 Vol -	 Vol -
 Display	 Info	 Mute	 Mute
 Freeze	 Pause	 CH +	 Ch +
 Sleep	 Sleep	 CH -	 Ch -
 On / Off	 Text	 Pic Mode	 Format
 Mix	 Shift + Text	 I/II	 Dual
 Index	 List	 Sound Sys	 Shift + Dual
 Size	 Eject	 Up	 Up
 Reveal	 Media	 Right	 Right
 Update	 Smart	 Down	 Down
 Subpage	 Subt	 Left	 Left
 Hold	 Stop	 Menu	 Menu
 Red	 Red	 1	 1
 Green	 Green	 Menu	 Ok
 Yellow	 Yellow	 2	 2
 Blue	 Blue	 3	 3



