































| Original | Replacement |
|--|---|
|  TV |  TV/Radio / |
|  TV |  Shift + 1 |
|  Audio |  Audio / Lang I/II |
|  TV / VCR |  AV / Input / RDS |
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  Text |  Text / Goto |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  Subtitle |  Subtitle / EQ |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Sound |  Sound / Title |

| Original | Replacement |
|---|---|
|  Alt |  Fav / Marker / PC |
|  0 |  0 |
|  i |  Info / Angle |
|  Setup |  Setup / OPT / |
|  Exit |  Exit / Cancel / Clear |
|  Up |  Up |
|  Navigator |  Smart / List |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Vol + |  Vol+ |
|  Down |  Down |
|  CH + |  CH+ / Page+ |
|  Vol - |  Vol- |
|  Mute |  Mute / Dimmer |
|  Recall |  Back / Return |
|  CH - |  CH- / Page- |





| Original | | Replacement | | Original | Replacement |
|---|--------|---|-----------------------------|----------|-------------|
|  | Red |  | Red / Netflix / Search | | |
|  | Green |  | Green / APP / Repeat | | |
|  | Yellow |  | Yellow / YouTube / Repeat | | |
|  | Blue |  | Blue / Prime Video / Random | | |
|  | EPG |  | Guide / EPG / -/-- | | |
|  | Check |  | Display / Media | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

