









































































































Original	Replacement
 Power	 Power
 Mute	 Mute
 Play	 Play
 Pause / Mix	 Pause
 Pause / Mix	 Shift + Text
 Stop / Hold	 Stop
 Size	 Format
 << / Timer	 <<
 << / Timer	 Shift + Power
 I<< / Index	 I<<
 >>I / Reveal	 >>I
 >> / Cancel	 >>
 >> / Cancel	 Shift + Exit
 Info	 Info
 Audio / I/II	 Dual
 Text	 Text
 Back / Del	 Back

Original	Replacement
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Settings	 Options
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down





Original	Replacement	Original	Replacement
 Power	 Power	 Blue	 Blue
 Mute	 Mute	 Q.Menu	 D. Menu
 1	 1	 Back	 Back
 2	 2	 Up	 Up
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Menu	 Menu
 8	 8	 EPG	 Guide
 9	 9	 YouTube	 Shift + Media
 0	 0	 Vol +	 Vol +
 Info	 Info	 Vol -	 Vol -
 Audio / I/II	 Dual	 Home / Source	 AV
 Red	 Red	 Home / Source	 Smart
 Green	 Green	 Text	 Text
 Yellow	 Yellow	 P +	 Ch +



