







































































Original	Replacement	Original	Replacement
 POWER	 Power	 TEXT	 Text
 BLUE	 Blue	 SOURCE	 AV
 MUTE	 Mute	 MENU	 Menu
 PLAY	 Play	 UP	 Up
 PAUSE	 Pause	 INFO	 Info
 STOP	 Stop	 LEFT	 Left
 I<<	 I<<	 ENTER	 Ok
 <<	 <<	 RIGHT	 Right
 >>	 >>	 EXIT	 Exit
 >>I	 >>I	 DOWN	 Down
 LIST / REPEAT	 List	 RECALL	 Back
 AUDIO I/II	 Dual	 VOL+	 Vol +
 [≡o]	 Subt	 CH+	 Ch +
 [≡X]	 Options	 VOL-	 Vol -
 SLEEP	 Sleep	 CH-	 Ch -
 E/W	 TV/R	 1	 1
 SIZE / ASPECT	 Format	 2	 2





Original		Replacement		Original		Replacement	
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	FAV		Pre Ch				
	RED		Red				
	GREEN		Green				
	YELLOW		Yellow				

