







































































Original	Replacement	Original	Replacement
 Power	 Power	 Pause / Step	 Pause
 Open / Close	 Eject	 Play	 Play
 1	 1	 Stop	 Stop
 2	 2	 Home	 Smart
 3	 3	 Menu / List	 Menu
 4	 4	 Up / PR/CH +	 Up
 5	 5	 Up / PR/CH +	 Ch +
 6	 6	 Down / PR/CH -	 Down
 7	 7	 Down / PR/CH -	 Ch -
 8	 8	 Left	 Left
 9	 9	 Enter	 Ok
 0	 0	 Right	 Right
 AV / Input	 AV	 Display	 Info
 << Scan	 <<	 Return	 Back
 Scan >>	 >>	 Audio	 Dual
 I<< Skip	 I<<	 Subtitle	 Subt
 Skip >>I	 >>I	 Zoom	 Shift + Eject



