



Original	Replacement
 POWER	 Power
 SOURCE	 AV
 ASPECT	 Format
 MENU	 Menu
 S.MODE	 Shift + Dual
 P.MODE	 Shift + Format
 1	 1
 2	 2
 3	 3
 MUTE	 Mute
 4	 4
 5	 5
 6	 6
 DISPLAY	 Info
 7	 7
 8	 8
 9	 9

Original	Replacement
 TEXT	 Text
 0	 0
 RECALL	 Back
 TV	 TV/R
 ^	 Up
 >	 Right
 V	 Down
 <	 Left
 MENU	 Ok
 VOL+	 Vol +
 VOL-	 Vol -
 CH-	 Ch -
 CH+	 Ch +
 SLEEP	 Sleep
 SUBCODE	 Subt
 ZOOM	 Eject
 STILL	 Pause





Original		Replacement		Original	Replacement
	REVEAL		Smart		
	RED		Red		
	GREEN		Green		
	YELLOW		Yellow		
	BLUE/HDMI		Blue		
	MIX		Guide		
	I/II		Dual		
	HOLD		Stop		
	CANCEL		Shift + Back		
	INDEX		Media		

