






































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	Picture		Format
	Sound		Shift + Dual
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu
	Exit		Exit

Original	Replacement	Original	Replacement
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	EPG/Size		Guide
	Subtitle/Index		Subt
	Sleep/Hold		Sleep
	Text		Text





Original	Replacement	Original	Replacement
 FAV/Sub.Code	 Pre Ch		
 Tv/Reveal	 TV/R		
 Comp/Mix	 Options		
 Lang/Cancel	 Dual		
 Info	 Info		
 Recall	 Back		
 I/II	 List		
 Zoom	 Eject		
 DMP	 Smart		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Display/DMP	 3D		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		

