



Original	Replacement
Power	Power
Mute	Mute / Dimmer
EQ	Subtitle / EQ
1	1
2	2
3	3
VFD	Blue / Prime Video / Random
4	4
5	5
6	6
L/R	Red / Netflix / Search
7	7
8	8
9	9
P/N	Yellow / YouTube / Repeat
Repeat	Green / APP / Repeat
0/10	0

Original	Replacement
10+	Guide / EPG / -/-
Zoom	Zoom / Size
TV Mode	Shift + 1
I<<	I<< / Preset-
>>I	>>I / Preset+
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
<<	<< / Tune-
>>	>> / Tune+
USB/Card	Shift + 8
Up	Up
Menu	Menu / Home
Left	Left
Enter	OK
Right	Right
Clock	Sleep / Timer



