








































































Original	Replacement
 Power	 Power
 Open/Close	 Eject / Surround
 Function	 AV / Input / RDS
 1/RDS Display	 1
 2	 2
 3/TA	 3
 4/PTY-	 4
 5/PTY Search	 5
 6/PTY+	 6
 7	 7
 8	 8
 9	 9
 Disc Menu	 D.Menu / Top
 0	 0
 Title Menu PopUp	 Shift + D.Menu / Top Menu
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+

Original	Replacement
 <<	 << / Tune-
 >>	 >> / Tune+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 Tuning/CH-	 CH- / Page-
 Tuning/CH+	 CH+ / Page+
 Vol-	 Vol-
 Tv Sound	 Sound / Title
 S/W Level	 Picture / Format
 Home	 Menu / Home
 Sleep	 Sleep / Timer
 Tools	 Setup / OPT /
 Up	 Up
 Info	 Info / Angle









































































Original	Replacement
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow/Tuner	 Yellow / YouTube / Repeat
 Blue/Mo/St	 Blue / Prime Video / Random
 Smart Hub	 Smart / List
 Search	 Shift + Red / Netflix /
 Sound Effect	 Shift + Sound / Title
 3D/Sound	 Audio / Lang I/II

Original	Replacement





Original		Replacement		Original		Replacement	
	Power		Power		Play		Play / Slow
	Function		AV / Input / RDS		Pause		Pause / Step / Freeze
	1/RDS Display		1		Vol+		Vol+
	2		2		Mute		Mute / Dimmer
	3/TA		3		Tuning/CH-		CH- / Page-
	4/PTY-		4		Tuning/CH+		CH+ / Page+
	5/PTY Search		5		Vol-		Vol-
	6/PTY+		6		Tv Sound		Sound / Title
	7		7		Home		Menu / Home
	8		8		Sleep		Sleep / Timer
	9		9		Tools		Setup / OPT /
	0		0		Up		Up
	I<<		I<< / Preset-		Info		Info / Angle
	>>I		>>I / Preset+		Left		Left
	<<		<< / Tune-		Enter		OK
	>>		>> / Tune+		Right		Right
	Stop		Stop / Hold		Return		Back / Return





Original		Replacement		Original		Replacement	
	Down		Down				
	Exit		Exit / Cancel / Clear				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow/Tuner		Yellow / YouTube / Repeat				
	Blue/Mo/St		Blue / Prime Video / Random				
	Smart Hub		Smart / List				
	Search		Shift + Red / Netflix /				

