






































| Original | Replacement |
|---|--|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -- |  Guide |
|  P<P |  Pre Ch |
|  Menu |  Menu |
|  [i] |  Info |
|  Up / P+ |  Up |
|  Up / P+ |  Ch + |

| Original | Replacement |
|--|--|
|  Down / P- |  Down |
|  Down / P- |  Ch - |
|  Right / Vol+ |  Right |
|  Right / Vol+ |  Vol + |
|  Left / Vol- |  Left |
|  Left / Vol- |  Vol - |
|  OK |  Ok |
|  I/II |  Dual |
|  PP |  Back |
|  TV |  TV/R |
|  AV |  AV |
|  Mute |  Mute |
|  Red / Sound |  Red |
|  Red / Sound |  Shift + Dual |
|  Green / Picture |  Format |
|  Green / Picture |  Green |
|  Yellow / Feature |  Yellow |





| Original | Replacement | Original | Replacement |
|----------------|-----------------|----------|-------------|
| Blue / Install | Blue | | |
| [=] | Text | | |
| [=⊖] | Sleep | | |
| [=□] | Stop | | |
| [=X] / [■ ■] | Exit | | |
| [/ =] [■] | + Shift + Text | | |
| [=↑] / [□] | Eject | | |
| [=?] / PC | Smart | | |
| [=i] | Options | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

