



































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Recall / [≡?]	 Back	 Vol+	 Vol +
 Mute	 Mute	 Vol-	 Vol -
 Input	 AV	 VIDEO+	 Smart
 Red	 Red	 A.TRK	 Media
 Green	 Green	 Sleep	 Sleep
 Yellow	 Yellow	 PR/Page+	 Ch +
 Blue	 Blue	 PR/Page-	 Ch -
 1	 1	 [≡X]	 Exit
 2	 2	 Normal	 3D
 3	 3	 [≡]	 Text
 4	 4	 Menu	 Menu
 5	 5	 Up / [ /≡]	 Up
 6	 6	 Left	 Left
 7	 7	 [≡i]	 Ok
 8	 8	 [≡i]	 Info
9	9	Right	Right










































Original		Replacement		Original		Replacement	
	Down / Still / [≡●]		Down				
	OTR / [≡□]		Stop				
	[≡↓]		Format				
	SP / LP		Dual				
	Eject		Eject				





Original	Replacement
 Power	 Power
 Counter Reset	 Red
 Counter Stop	 Green
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back
 VIDEO+	 Smart
 A.TRK	 Media
 TRK+	 Ch +

Original	Replacement
 TRK+	 >>I
 TRK-	 Ch -
 TRK-	 I<<
 Menu	 Menu
 Rec/OTR	 Rec
 SP / LP	 Options
 Eject	 Eject
 Play	 Play
 REW	 <<
 Stop	 Stop
 FF	 >>
 Pause / Still	 Pause

