





Original	Replacement
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	Guide
Preview	Pre Ch
Sound	Dual
Picture	Shift + Format
Aspect	Format

Original	Replacement
Still	Pause
S.Mode	Shift + Dual
Sleep	Sleep
Volume+	Vol +
Volume-	Vol -
Channel+	Ch +
Channel-	Ch -
PIP On/Off	Smart
Source	Shift + AV
Size	Eject
Swap	Back
Up / P-CH +	Up
Down / P-CH -	Down
Right	Right
Left	Left
Menu	Menu
Menu	Ok





Original	Replacement
	 Exit
	 AV
	 Info
	 Media
	 Options
	 Text
	 Shift + Text
	 Shift + Info
	 Shift + Smart
	 TV/R
	 Stop
	 Shift + Subt
	 Subt
	 Shift + Eject
	 Red
	 Green
	 Yellow

Original	Replacement
	 Blue

