









































































































| Original | | Replacement | | Original | | Replacement | |
|---|---------|---|-------------------|---|-----------|---|----------------------------|
|  | Mute |  | Mute / Dimmer |  | 6 |  | 6 |
|  | Power |  | Power |  | A/B |  | Shift + Yellow / YouTube / |
|  | (↔) |  | Audio / Lang I/II |  | 7 |  | 7 |
|  | TV |  | TV/Radio / |  | 8 |  | 8 |
|  | ∨ |  | Sound / Title |  | 9 |  | 9 |
|  | [#]→ |  | Picture / Format |  | Output |  | AV / Input / RDS |
|  | [.≡] |  | Text / Goto |  | -/-- |  | Guide / EPG / -/-- |
|  | [≡+] |  | Shift + Stop / |  | 0 |  | 0 |
|  | [≡◆] |  | Shift + Zoom / |  | C |  | Exit / Cancel / Clear |
|  | [≡x]⊙ |  | Back / Return |  | IN 123 |  | D.Menu / Top |
|  | [≡?][+] |  | Sleep / Timer |  | 1-/TP Off |  | Fav / Marker / PC |
|  | 1 |  | 1 |  | C00 |  | Setup / OPT / |
|  | 2 |  | 2 |  | 2-/TP On |  | Shift + Fav / Marker / PC |
|  | 3 |  | 3 |  | Vol+ |  | Vol+ |
|  | [≡i] |  | Info / Angle |  | Prog+ |  | CH+ / Page+ |
|  | 4 |  | 4 |  | Vol- |  | Vol- |
|  | 5 |  | 5 |  | Prog- |  | CH- / Page- |





| Original | Replacement |
|---|---|
|  |  Red / Netflix / Search |
|  |  Green / APP / Repeat |
|  |  Yellow / YouTube / Repeat |
|  |  Blue / Prime Video / Random |
|  |  Display / Media |
|  |  Left |
|  |  Right |
|  |  Zoom / Size |
|  |  Menu / Home |
|  |  Smart / List |
|  |  OK |
|  |  Up |
|  |  Subtitle / EQ |
|  |  >>I / Preset+ |
|  |  Shift + Right |
|  |  Down |
|  |  Shift + CH+ / |

| Original | Replacement |
|---|---|
|  |  I<< / Preset- |
|  |  Shift + Left |
|  |  Shift + Power |
|  |  Shift + CH- / |
|  |  << / Tune- |
|  |  Play / Slow |
|  |  >> / Tune+ |
|  |  Stop / Hold |
|  |  Pause / Step / Freeze |



