


































































	Original	Replacement		Original	Replacement
			Power		 Dual
			Open/Close		 AV
			1		 Mute
			2		 Vol +
			3		 Vol -
			4		 Up
			5		 Down
			6		 Right
			7		 Left
			8		 Ok
			9		 >>
			0		 <<
ALARM1	Alarm1		Red		 Stop
ALARM2	Alarm2		Blue		 Play
CLOCK	Clock	 + 	Shift + AV		 Pause
SLEEP	Sleep		Sleep		 Text
DISPLAY	Display		Info		 Media





Original	Replacement	Original	Replacement
	Intro		Guide
	Folder+		Ch +
	Folder-		Ch -

