



Original		Replacement		Original		Replacement	
	Power		Power		Rec		Rec
	Mute		Mute		Menu		Menu
	Red		Red		Exit		Exit
	Green		Green		Up		Up
	Yellow		Yellow		Left		Left
	Blue		Blue		OK		Ok
	Subtitle		Subt		Right		Right
	Text		Text		Down		Down
	Audio		Dual		EPG		Guide
	Recall		Back		i		Info
	<<		<<		V+		Vol +
	>>		>>		V-		Vol -
	I<<		I<<		FAV		Pre Ch
	>>I		>>I		P+		Ch +
	Play		Play		Go To		Media
	Pause		Pause		P-		Ch -
	Stop		Stop		1		1





























































	Original	Replacement	Original	Replacement
	2	2		
	3	3		
	4	4		
	5	5		
	6	6		
	7	7		
	8	8		
	9	9		
	0	0		
	OPT	SETTINGS OPT		
	TV/RADIO	SEARCH TV/R		



























Original	Replacement	Original	Replacement
 POWER	 Power	 MUTE	 Mute
 EXIT	 Exit	 EMAIL	 Options
 MENU	 Menu	 TXT	 Text
 AUDIO	 Dual	 TV / RADIO	 TV/R
 APP	 Media	 OK	 Ok
 1	 1	 UP	 Up
 2	 2	 DOWN	 Down
 3	 3	 RIGHT	 Right
 4	 4	 LEFT	 Left
 5	 5	 PAGE UP	 Ch +
 6	 6	 PAGE DOWN	 Ch -
 7	 7	 VOL+	 Vol +
 8	 8	 VOL-	 Vol -
 9	 9	 SUB.	 Subt
 0	 0	 RECALL	 Back
 ---	 Shift + Guide	 RED	 Red
 FAV	 Pre Ch	 GREEN	 Green





Original	Replacement	Original	Replacement
 YELLOW	 Yellow		
 BLUE	 Blue		
 STOP	 Stop		
 PAUSE	 Pause		
 REC	 Rec		
 REW	 <<		
 PLAY	 Play		
 FWD	 >>		
 EPG	 Guide		
 i	 Info		
 GO TO	 AV		

