









































































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Smart	Menu Off	 Exit
Reveal	 Media	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8		
9	 9		
Guide -/-- 1.	 Guide		
0/10	 0		
2.Fav P/C 2.	 Pre Ch		
Red	 Red		
Green	 Green		
Yellow	 Yellow		
Mix Scan	 Pause		
On/Tim	 Play		
Blue	 Blue		
Audio+	 List		
Aft/Caf	 Rec		
Store Text	 +  Shift + Text		
Tone-	 <<		
Store	 Options		
Disp	 3D		

Original	Replacement	Original	Replacement
Tone+	 >>		
AV 2	 +  Shift + AV		
Search	 +  Shift + TV/R		
Tune-	 +  Shift + Left		
Tune+	 +  Shift + Right		
Input	 +  Shift + Vol +		
Contrast+	 +  Shift + Ch +		
Output	 +  Shift + Vol -		
Contrast-	 +  Shift + Ch -		
3.*	 +  Shift + Guide		
4.# 16:9	 Format		
Surround	 +  Shift + Red		
Nicam/Mono	 +  Shift + Green		
Level L	 +  Shift + Yellow		
Level R/Woofer	 +  Shift + Blue		

