































Original	Replacement
 Power	 Power
 [i+]	 Info
 AV1	 AV
 AV1	 Shift + 1
 Rec/AV2	 Shift + 2
 Rec/AV2	 Rec
 Stop/AV3	 Shift + 3
 Stop/AV3	 Stop
 Play/AV4	 Shift + 4
 Play/AV4	 Play
 AV5	 Shift + 5
 AV5	 Shift + AV
 Pause/AV6	 Shift + 6
 Pause/AV6	 Pause
 <</RGB1	 Shift + 7
 <</RGB1	 <<
 >>/RGB2	 >>

Original	Replacement
 >>/RGB2	 Shift + 8
 Menu	 Menu
 [>I<]/Recall	 Pre Ch
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 J/S.Mode	 Shift + Dual
 (I)/P.Mode	 Shift + Format
 Vol+	 Vol +
 Vol-	 Vol -
 I/II	 Dual
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 1	 1

































Original		Replacement		Original		Replacement	
	2		2		[...]/Slide Show		Subt
	3		3		[=]/Rotate		3D
	4		4		[=]		Text
	5		5		[<>]		Format
	6		6		Swivel		Smart
	7		7		Photo		Media
	8		8				
	9		9				
	0		0				
	[   ]/2-4-12		Back				
	[   ]		Guide				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[=i]		Options				
	[=x]		TV/R				










































	Original	Replacement	Original	Replacement
	Power			
	OK			
	Up			
	Down			
	Right			
	Left			
	Menu			
	Stop			
	Play			
	Pause			
	<<			
	>>			
	P+			
	P-			





	Original	Replacement		Original	Replacement
	Power		Power		8
	OK		Ok		9
	Up		Up		0
	Down		Down		
	Right		Right		
	Left		Left		
	Vol+		Vol +		
	Vol-		Vol -		
	P+		Ch +		
	P-		Ch -		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		

