





































Original	Replacement
 Power	 Power
 TV/AV	 AV
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Recall	 Back
 Vol+	 Vol +
 Vol-	 Vol -

Original	Replacement
 A1 (no name)	 Shift + 1
 A2 (no name)	 Shift + 2
 B2 (no name)	 Shift + 3
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Menu	 Menu
 Exit	 Exit
 Picture	 Shift + Format
 Sound	 Shift + Dual
 Sleep	 Sleep
 Display	 Info
 Eject/Aspect	 Format





Original	Replacement
 Eject/Aspect	 Eject
 FAV	 Pre Ch
 Play	 Play
 Pause	 Pause
 Stop/Nicam/A2	 Stop
 Goto/Auto	 Media
 Setup	 Options
 Title	 List
 Angle	 3D
 Audio	 Dual
 D.Menu/Text	 Text
 D.Menu/Text	 D. Menu
 D.Switch/Hold	 Smart
 Repeat/PgDn	 Shift + Text
 Repeat/PgDn	 Shift + Ch -
 Subtitle/PgUp	 Subt
 Subtitle/PgUp	 Shift + Ch +

Original	Replacement
 <</Index	 <<
 >>/Size	 >>
 I<</Reveal	 I<<
 >>I/Subpage	 >>I
 Red/Program	 Red
 Red/Program	 Shift + Sleep
 Green/Zoom	 Green
 Green/Zoom	 Shift + Eject
 Yellow/Slow	 Yellow
 Cyan/A-B	 Blue

