


































































Original	Replacement
 Power	 Power
 Eject	 Eject / Surround
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 OSD / Info	 Display / Media
 OSD / Info	 Info / Angle
 4	 4
 5	 5
 6	 6
 V-Mode	 Picture / Format
 7	 7
 8	 8
 9	 9
 P/N / Fav	 Fav / Marker / PC
 0	 0

Original	Replacement
 10+	 Shift + Guide / EPG / -/-
 Goto	 Shift + Text /
 Setup	 Setup / OPT /
 Angle	 Shift + Info / Angle
 Text / Title	 Sound / Title
 Text / Title	 Text / Goto
 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 PBC / EPG	 Guide / EPG / -/-
 Source	 AV / Input / RDS
 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-





Original	Replacement
Play / Pause	Play / Slow
Play / Pause	Pause / Step / Freeze
I<<	I<< / Preset-
>>	>> / Tune+
Stop	Stop / Hold
>>I	>>I / Preset+
Red / Prog	TV/Radio /
Red / Prog	Red / Netflix / Search
Green / Step	Green / APP / Repeat
Green / Step	Shift + Pause / Step /
Yellow / Repeat	Yellow / YouTube / Repeat
Yellow / Repeat	Shift + Green / APP /
Blue / A-B	Blue / Prime Video / Random
Blue / A-B	Shift + Yellow / YouTube /
Zoom	Zoom / Size
Slow	Shift + Play /
Vocal	D.Menu / Top

Original	Replacement
Audio	Audio / Lang I/II
CH-	CH- / Page-
CH+	CH+ / Page+
Vol-	Vol-
Vol+	Vol+

