




































































































| Original | Replacement | Original | Replacement |
|--|--|--|---|
|  Power |  Power |  5 |  5 |
|  Language |  Dual |  6 |  6 |
|  Menu |  Menu |  7 |  7 |
|  Open/Close |  Eject |  8 |  8 |
|  Goto |  Green |  9 |  9 |
|  Angle |  Red |  10/0 |  0 |
|  Prog |  Sleep |  10+ |  Guide |
|  PBC |  Yellow |  USB |  AV |
|  N/P |  Blue |  Repeat |  Text |
|  RL |  3D |  A-B |  D. Menu |
|  Clear |  Exit |  Title |  Smart |
|  Step |  TV/R |  Return |  Back |
|  V-Mode |  Format |  OSD |  Info |
|  1 |  1 |  Slow |  List |
|  2 |  2 |  Zoom |  Shift + Eject |
|  3 |  3 |  Setup |  Options |
|  4 |  4 |  Subt |  Subt |





| Original | Replacement | Original | Replacement |
|---|-------------|---|-------------|
|  | Up |  | Up |
|  | Left |  | Left |
|  | Enter |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Pause |  | Pause |
|  | Mute |  | Mute |
|  | Stop |  | Stop |
|  | << |  | << |
|  | >> |  | >> |
|  | Play |  | Play |
|  | I<< |  | I<< |
|  | >>I |  | >>I |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
| | | | |
| | | | |

