




























































| Original | Replacement | Original | Replacement |
|--------------|---|------------|---|
| On/Off |  Power | Text |  Text / Goto |
| Mute |  Mute / Dimmer | TV/AV |  AV / Input / RDS |
| Update |  Play / Slow | Menu |  Menu / Home |
| Reveal |  Pause / Step / Freeze | Menu Up |  Up |
| Txt Stop |  Stop / Hold | Info |  Info / Angle |
| Tone- |  << / Tune- | Menu Left |  Left |
| Tone+ |  >> / Tune+ | OK Enter |  OK |
| Contrast- |  I<< / Preset- | Menu Right |  Right |
| Contrast+ |  >>I / Preset+ | Menu Off |  Exit / Cancel / Clear |
| Color- S.Std |  Sound / Title | Menu Down |  Down |
| Menu audio |  Audio / Lang I/II | Back |  Back / Return |
| Subt.List |  Subtitle / EQ | Volume+ |  Vol+ |
| Color+ P.Std |  Picture / Format | On/Tim |  Smart / List |
| Txt Expand |  Zoom / Size | Chan.Up |  CH+ / Page+ |
| Sleep Timer |  Sleep / Timer | Volume- |  Vol- |
| Return TV |  TV/Radio / | Display |  Display / Media |
| Menu video |  D.Menu / Top | Chan.Down |  CH- / Page- |



| Original | Replacement | Original | Replacement |
|---------------|---|----------------|--|
| 1 |  1 | 4.# 16:9 |  Shift + Picture / Format |
| 2 |  2 | Mix Scan |  Shift + Text / |
| 3 |  3 | Level L |  Shift + Left |
| 4 |  4 | Level R/Woofer |  Shift + Right |
| 5 |  5 | Audio+ |  Shift + Vol+ |
| 6 |  6 | Off/Tim |  Shift + Smart / List |
| 7 |  7 | Audio- |  Shift + Vol- |
| 8 |  8 | 3.* |  Shift + 0 |
| 9 |  9 | | |
| Guide -/-- 1. |  Guide / EPG / -/-- | | |
| 0/10 |  0 | | |
| 2.Fav P/C 2. |  Fav / Marker / PC | | |
| Red |  Red / Netflix / Search | | |
| Green |  Green / APP / Repeat | | |
| Yellow |  Yellow / YouTube / Repeat | | |
| Blue |  Blue / Prime Video / Random | | |
| Nicam/Mono |  Shift + Audio / Lang I/II | | |

