




















































	Original	Replacement		Original	Replacement
	Power		Power		Vol +
	Mute		Mute		Vol -
	1		1		Ch +
	2		2		Ch -
	3		3		Exit
	4		4	>>I icon" data-bbox="511 391 539 431"/>	>>I
	5		5		Ok
	6		6		Menu
	7		7		Right
	8		8		Left
	9		9		AV
	0		0		Smart
	-/-		Guide		Media
	i		Info		Text
	OO		Dual		D. Menu
	Picture		Format		TV/R
	⊖ Sleep		3D		<<





Original	Replacement	Original	Replacement
[=>1]	>>		
[=O]	SETTINGS OPT Options		

