








Original	Replacement
	Power
	Mute
	P.Mode
	S.Mode
	FAV
	Sleep
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Shift + Guide / EPG / -/--
	0

Original	Replacement
	Back
	Vol+
	CH List
	CH+
	Vol-
	Aspect
	CH-
	EPG
	Audio
	Rec
	Menu
	Up
	Exit
	Left
	Enter
	Right
	Source





Original		Replacement	
	Down		Down
	Display		Display / Media
	Red		Red / Netflix / Search
	<<		<< / Tune-
	Green		Green / APP / Repeat
	>>		>> / Tune+
	Yellow		Yellow / YouTube / Repeat
	l<<		l<< / Preset-
	Blue		Blue / Prime Video / Random
	>>		>> / Preset+
	Text		Text / Goto
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Index		Info / Angle
	Size		Zoom / Size
	Reveal		D.Menu / Top

Original		Replacement	
	Hold	+	Shift + Stop /
	Subpage		Eject / Surround
	Subtitle		Subtitle / EQ



Menu