


























































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PSM	 Format
 SSM	 Shift + Dual
 List	 List
 ARC	 3D
 I/II	 Dual

Original	Replacement
 Menu	 Menu
 A.Swap	 Back
 Input	 AV
 Text	 Text
 Q.View	 Options
 Sleep	 Sleep
 Exit	 Exit
 Up / PR+	 Up
 Up / PR+	 Ch +
 Left / Vol-	 Vol -
 Left / Vol-	 Left
 OK	 Ok
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Down / PR-	 Ch -
 Down / PR-	 Down
 Red / PIP PR+	 Red





Original	Replacement
 Green / PIP PR-	 Green
 Yellow / Swap	 Yellow
 Blue / PIP Input	 Blue
 Mix	 Shift + Text
 Index	 Media
 Time	 Shift + AV
 Reveal	 Play
 M.Mode	 >>
 Size	 Eject
 Hold	 Stop
 Update	 <<
 PIP	 Smart
 PIP Positino	 Rec
 Still	 Pause
 Scan	 I<<
 Audio	 D. Menu
 Info	 Info

Original	Replacement
 EPG	 Guide
 Subt	 Subt
 DTV / Radio	 TV/R

