











































































































Original		Replacement		Original		Replacement	
	Power		Power		Stop / Reveal		Stop
	Mute		Mute		<< / Hold		<<
	Red		Red		>> / Subpage		>>
	Green		Green		l<< / Size		l<<
	Yellow		Yellow		>>l / Cancel		>>l
	Blue		Blue		Info		Info
	EPG		Guide		Input		AV
	Rec		D. Menu		Up		Up
	Rec. List		Eject		Left		Left
	T-Shift		3D		OK		Ok
	Sub-T		Subt		Right		Right
	Audio		Dual		Down		Down
	Sleep		Sleep		Menu		Menu
	TV/Radio		TV/R		Exit		Exit
	Text		Text		Vol+		Vol +
	Play / Index		Play		Vol-		Vol -
	Pause / Mix		Pause		P-Mode		Format





Original	Replacement
 S-Mode	 List
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--	 Shift + Guide
 0	 0
 Recall	 Back
 Fav	 Pre Ch
 Fav+	 Smart

Original	Replacement
 Fav-	 Media

