


































































































Original		Replacement		Original		Replacement	
	Power		Power		PR+		Ch +
	Source		AV		Vol-		Vol -
	HDMI		Media		CH List		List
	1		1		PR-		Ch -
	2		2		Smart/Hub		Smart
	3		3		Menu		Menu
	4		4		Guide		Guide
	5		5		Tools		Options
	6		6		Up		Up
	7		7		Info		Info
	8		8		Left		Left
	9		9		Enter		Ok
	TTX/MIX		Text		Right		Right
	0		0		Return		Back
	PRE-CH		Pre Ch		Down		Down
	Vol+		Vol +		Exit		Exit
	Mute		Mute		Red/A		Red





Original	Replacement	Original	Replacement
 Green/B	 Green		
 Yellow/C	 Yellow		
 Blue/D	 Blue		
 TV Social	 Sleep		
 Search	 TV/R		
 3D	 3D		
 E-Manual	 D. Menu		
 D	 Dual		
 AD/Subt	 Subt		
 <</ <<	 <<		
 Pause	 Pause		
 >>/>>	 >>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

