


































	Original	Replacement	Original	Replacement
	Power			
	DBB			
	Source			
	Repeat			
	Play			
	Pause			
	Stop			
	>>I			
	I<<			
	Prog			
	Vol+			
	Vol-			
	Mute			
	Preset+			
	Preset-			
	Display	