


































Original	Replacement	Original	Replacement
 Power	 Power	 Subtitle	 Subtitle / EQ
 Open/Close	 Text / Goto	 Angle	 Red / Netflix / Search
 1	 1	 Sur	 Eject / Surround
 2	 2	 Search Mode	 AV / Input / RDS
 3	 3	 Repeat	 Shift + Setup / OPT / Tools
 4	 4	 A-B	 Shift + Play /
 5	 5	 Shuffle	 Yellow / YouTube / Repeat
 6	 6	 SA-CD	 Smart / List
 7	 7	 Album+	 CH+ / Page+
 8	 8	 Album-	 CH- / Page-
 9	 9	 Zoom	 Shift + Text /
 0	 0	 Picture Navi	 Zoom / Size
 Clear	 Exit / Cancel / Clear	 >>	 >>  / Preset+
 Enter	 Fav / Marker / PC	  <<	 << / Tune-
 Time/Text	 Setup / OPT /	 >> /  >	  << / Preset-
 Picture Mode	 Sleep / Timer	 << / <	 >> / Tune+
 Audio	 Audio / Lang I/II	 ← / <	 Shift + << /

Original	Replacement	Original	Replacement
 Subtle	 Subtitle / EQ	 Angle	 Red / Netflix / Search
 Sur	 Eject / Surround	 Search Mode	 AV / Input / RDS
 Repeat	 Shift + Setup / OPT / Tools	 A-B	 Shift + Play /
 Shuffle	 Yellow / YouTube / Repeat	 SA-CD	 Smart / List
 Album+	 CH+ / Page+	 Album-	 CH- / Page-
 Zoom	 Shift + Text /	 Picture Navi	 Zoom / Size
 >>	 >>  / Preset+	  <<	 << / Tune-
 >> /  >	  << / Preset-	 << / <	 >> / Tune+
 ← / <	 Shift + << /		

Tune-






Original	Replacement
   > / →	 +  Shift + >> / Preset+
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 OK
 Display	 Info / Angle
 Menu	 Menu / Home
 Top Menu	 +  Shift + Menu /
 Return	 Back / Return
 Stop	 Stop / Hold
 SA-CD/CD	 Display / Media

Original	Replacement







Original	Replacement	Original	Replacement
 Power	 Power		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Enter	 OK		
 Input	 AV / Input / RDS		
 Vol+	 Vol+		
 Vol-	 Vol-		

