





| Original | Replacement | Original | Replacement |
|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
|  TV/RAD |  TV/Radio / |  Vol+ |  Vol+ |
|  Power |  Power |  Mute |  Mute / Dimmer |
|  Input |  AV / Input / RDS |  P+/Page Up |  CH+ / Page+ |
|  AV Mode |  Picture / Format |  Vol- |  Vol- |
|  Power Saving |  Eject / Surround |  P-/Page Down |  CH- / Page- |
|  1 |  1 |  Up |  Up |
|  2 |  2 |  Left |  Left |
|  3 |  3 |  OK |  OK |
|  4 |  4 |  Right |  Right |
|  5 |  5 |  Menu |  Menu / Home |
|  6 |  6 |  Down |  Down |
|  7 |  7 |  Return / Exit |  Back / Return |
|  8 |  8 |  Red |  Red / Netflix / Search |
|  9 |  9 |  Green |  Green / APP / Repeat |
|  List |  Smart / List |  Yellow |  Yellow / YouTube / Repeat |
|  0 |  0 |  Blue |  Blue / Prime Video / Random |
|  Q.View |  Display / Media |  Text/[≡] |  Text / Goto |





| Original | Replacement | Original | Replacement |
|----------|--------------------|----------|-------------|
| T.OPT | Setup / OPT / | | |
| Subtitle | Subtitle / EQ | | |
| FAV | Fav / Marker / PC | | |
| Q.Menu | D.Menu / Top | | |
| Info | Info / Angle | | |
| Guide | Guide / EPG / -/-- | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

