



| Original | Replacement |
|----------|------------------------------|
| Power | Power |
| Mute | Mute / Dimmer |
| TV | TV/Radio / |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Recall | Back / Return |
| Exit | Exit / Cancel / Clear |
| List | Smart / List |
| APP | Shift + Green / APP / Repeat |

| Original | Replacement |
|----------|-----------------------------|
| EPG | Guide / EPG / -/-- |
| OPT | Setup / OPT / |
| OK | OK |
| Up | Up |
| Down | Down |
| Left | Left |
| Right | Right |
| Vol+ | Vol+ |
| Vol- | Vol- |
| CH/Page+ | CH+ / Page+ |
| CH/Page- | CH- / Page- |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| Text | Text / Goto |
| Sub | Subtitle / EQ |



