






















































































































| Original | Replacement | Original | Replacement |
|--------------|---|------------|---|
| On/Off |  Power | Return TV |  TV/Radio / |
| Mute |  Mute / Dimmer | Menu video |  D.Menu / Top |
| Update |  Play / Slow | Output |  Setup / OPT / |
| Still |  Pause / Step / Freeze | Text |  Text / Goto |
| Txt Stop |  Stop / Hold | Input |  AV / Input / RDS |
| Reveal |  Rec / Rec Mode | Menu |  Menu / Home |
| Tone- |  << / Tune- | Menu Up |  Up |
| Tone+ |  >> / Tune+ | Info |  Info / Angle |
| Camera1 |  I<< / Preset- | Menu Left |  Left |
| AV 2 |  >>I / Preset+ | OK Enter |  OK |
| Color- S.Std |  Sound / Title | Menu Right |  Right |
| Menu audio |  Audio / Lang I/II | Menu Off |  Exit / Cancel / Clear |
| Subt.List |  Subtitle / EQ | Menu Down |  Down |
| Surround |  Eject / Surround | Swap |  Back / Return |
| Color+ P.Std |  Picture / Format | Volume+ |  Vol+ |
| Txt Expand |  Zoom / Size | On/Tim |  Smart / List |
| Sleep Timer |  Sleep / Timer | Chan.Up |  CH+ / Page+ |
























| Original | Replacement | Original | Replacement |
|---------------|--|-------------|---|
| Volume- |  Vol- | Yellow |  Yellow / YouTube / Repeat |
| Display |  Display / Media | Blue |  Blue / Prime Video / Random |
| Chan.Down |  CH- / Page- | Game Coo |  +  Shift + << / |
| 1 |  1 | Nicam/Mono |  +  Shift + Audio / Lang I/II |
| 2 |  2 | 4.# 16:9 |  +  Shift + Picture / Format |
| 3 |  3 | Bright- Sys |  +  Shift + Setup / OPT / Tools |
| 4 |  4 | Mix Scan |  +  Shift + Text / |
| 5 |  5 | TV/AV |  +  Shift + AV / Input / RDS |
| 6 |  6 | Camera |  +  Shift + Info / Angle |
| 7 |  7 | Dim Pip |  +  Shift + Left |
| 8 |  8 | On Pip |  +  Shift + OK |
| 9 |  9 | Rotate Pip |  +  Shift + Right |
| Guide -/-- 1. |  Guide / EPG / -/-- | Clear |  +  Shift + Exit / Cancel / Clear |
| 0/10 |  0 | Back |  +  Shift + Back / Return |
| 2.Fav P/C 2. |  Fav / Marker / PC | Audio+ |  +  Shift + Vol+ |
| Red |  Red / Netflix / Search | Off/Tim |  +  Shift + Smart / List |
| Green |  Green / APP / Repeat | Disp |  +  Shift + Display / Media |



| Original | Replacement | Original | Replacement |
|--------------|---|------------|---|
| On/Off |  Power | TV/AV |  AV / Input / RDS |
| Mute |  Mute / Dimmer | Menu |  Menu / Home |
| Update |  Play / Slow | Menu Up |  Up |
| Reveal |  Pause / Step / Freeze | Info |  Info / Angle |
| Txt Stop |  Stop / Hold | Menu Left |  Left |
| Contrast- |  I<< / Preset- | OK Enter |  OK |
| Contrast+ |  >>I / Preset+ | Menu Right |  Right |
| Color- S.Std |  Sound / Title | Menu Off |  Exit / Cancel / Clear |
| Menu audio |  Audio / Lang I/II | Menu Down |  Down |
| Subt.List |  Subtitle / EQ | Back |  Back / Return |
| Color+ P.Std |  Picture / Format | Volume+ |  Vol+ |
| Txt Expand |  Zoom / Size | Disp |  Smart / List |
| Sleep Timer |  Sleep / Timer | Chan.Up |  CH+ / Page+ |
| Return TV |  TV/Radio / | Volume- |  Vol- |
| Menu video |  D.Menu / Top | Display |  Display / Media |
| Bright- Sys |  Setup / OPT / | Chan.Down |  CH- / Page- |
| Text |  Text / Goto | 1 |  1 |



| Original | Replacement | Original | Replacement |
|---------------|---|------------|---|
| 2 |  2 | Store Text |  +  Shift + Fav / Marker / PC |
| 3 |  3 | | |
| 4 |  4 | | |
| 5 |  5 | | |
| 6 |  6 | | |
| 7 |  7 | | |
| 8 |  8 | | |
| 9 |  9 | | |
| Guide -/-- 1. |  Guide / EPG / -/-- | | |
| 0/10 |  0 | | |
| 2.Fav P/C 2. |  Fav / Marker / PC | | |
| Red |  Red / Netflix / Search | | |
| Green |  Green / APP / Repeat | | |
| Yellow |  Yellow / YouTube / Repeat | | |
| Blue |  Blue / Prime Video / Random | | |
| Bright+ Mode |  +  Shift + Setup / OPT / Tools | | |
| Mix Scan |  +  Shift + Text / Goto | | |

