










































Original	Replacement
 On	 Power
 Standby	 Shift + Power
 HDMI 1	 1
 HDMI 2	 2
 Comp.	 3
 Video	 4
 S-Video	 5
 Info	 Info / Angle
 Lens	 Zoom / Size
 Aspect	 Picture / Format
 Hide	 Sleep / Timer
 Test	 Text / Goto
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down

Original	Replacement
 Menu	 Menu / Home
 Back	 Back / Return
 Cinema 1	 Shift + 1
 Cinema 2	 Shift + 2
 Cinema 3	 Shift + 3
 Natural	 Shift + 4
 Stage	 Shift + 5
 Dynamic	 Shift + 6
 User 1	 Shift + 7
 User 2	 Shift + 8
 Gamma	 Red / Netflix / Search
 C.Temp	 Green / APP / Repeat
 Lens AP.	 Yellow / YouTube / Repeat
 Pic. Adj.	 Blue / Prime Video / Random

