





































| Original   | Replacement   |
|--|---|
|  Power        |  Power           |
|  Open / Close |  Eject           |
|  1            |  1               |
|  2            |  2               |
|  3            |  3               |
|  4            |  4               |
|  5            |  5               |
|  6            |  6               |
|  7            |  7               |
|  8            |  8               |
|  9            |  9               |
|  0          |  0             |
|  -/--       |  Shift + Guide |
|  Recall     |  Back          |
|  Red        |  Red           |
|  Green      |  Green         |
|  Yellow     |  Yellow        |

| Original  | Replacement  |
|---|--|
|  Blue            |  Blue           |
|  P.Mode          |  Shift + Format |
|  S.Mode          |  Shift + Dual   |
|  Mute            |  Mute           |
|  TXT             |  Text           |
|  Aspect          |  Format         |
|  Nicam           |  Shift + 3D     |
|  Display         |  Info           |
|  Sleep           |  Sleep          |
|  Up / PR +       |  Up             |
|  Up / PR +       |  Ch +           |
|  Down / PR -   |  Down         |
|  Down / PR -   |  Ch -         |
|  Right / Vol + |  Right        |
|  Right / Vol + |  Vol +        |
|  Left / Vol -  |  Left         |
|  Left / Vol -  |  Vol -        |





| Original  |                       | Replacement   |              | Original  |                       | Replacement   |               |
|---|-----------------------|---|--------------|---|-----------------------|---|---------------|
|    | Enter                 |    | Ok           |    | A-B / FAV             |    | Pre Ch        |
|    | Source                |    | AV           |    | Left / << / Page Down |    | <<            |
|    | Menu                  |    | Menu         |    | Setup                 |    | Options       |
|    | Stop / Hold           |    | Stop         |    | Right / >> / Page Up  |    | Shift + Right |
|    | Play/Pause / Mix      |    | Play         |    | Right / >> / Page Up  |    | >>            |
|    | Play/Pause / Mix      |    | Pause        |    | Setup                 |    | Shift + Ok    |
|    | Subpage               |    | Shift + Subt |    | Zoom / Still          |    | Shift + Eject |
|    | Goto / Size           |    | Smart        |    | Language              |    | Dual          |
|    | Angle / Index         |    | 3D           |    | Title                 |    | Shift + Info  |
|    | Media / Reveal        |    | Media        |    | Down / >>I            |    | Shift + Down  |
|   | DVD Menu / DTV/Radio  |   | TV/R         |   | Down / >>I            |   | >>I           |
|  | DVD Menu / DTV/Radio  |  | D. Menu      |  | Subtitle              |  | Subt          |
|  | Up / I<< / List       |  | Shift + Up   |   |                       |   |               |
|  | Up / I<< / List       |  | List         |   |                       |   |               |
|  | Up / I<< / List       |  | I<<          |   |                       |   |               |
|  | Repeat / EPG          |  | Guide        |   |                       |   |               |
|  | Left / << / Page Down |  | Shift + Left |   |                       |   |               |

