







































































| Original    | Replacement   | Original   | Replacement   |
|-------------|---|------------|---|
| On/Off      |  Power   | Menu Right |  Right |
| Mute        |  Mute    | Menu Off   |  Exit  |
| Update      |  Media   | Menu Down  |  Down  |
| Reveal      |  Smart   | Back       |  Back  |
| Txt Stop    |  Stop    | Volume+    |  Vol + |
| Subt.List   |  Subt    | Chan.Up    |  Ch +  |
| Sleep Timer |  Sleep   | Volume-    |  Vol - |
| Return TV   |  TV/R    | Menu audio |  Dual  |
| Menu video  |  D. Menu | Chan.Down  |  Ch -  |
| Text        |  Text    | 1          |  1     |
| Txt Expand  |  Eject  | 2          |  2    |
| TV/AV       |  AV    | 3          |  3   |
| Menu        |  Menu  | 4          |  4   |
| Menu Up     |  Up    | 5          |  5   |
| Display     |  Info  | 6          |  6   |
| Menu Left   |  Left  | 7          |  7   |
| OK Enter    |  Ok    | 8          |  8   |






















| Original      | Replacement  | Original | Replacement |
|---------------|--|----------|-------------|
| 9             |  9      |          |             |
| Guide -/-- 1. |  Guide  |          |             |
| 0/10          |  0      |          |             |
| 2.Fav P/C 2.  |  Pre Ch |          |             |
| Red           |  Red    |          |             |
| Green         |  Green  |          |             |
| Yellow        |  Yellow |          |             |
| Blue          |  Blue   |          |             |
| 4.# 16:9      |  Format |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |
|               |  |          |             |



| Original     | Replacement   | Original   | Replacement   |
|--------------|---|------------|---|
| On/Off       |  Power   | OK Enter   |  Ok      |
| Audio Off    |  Mute  | Return     |  Back    |
| Slow Down    |  I<<   | Menu Right |  Right   |
| Subt.        |  Subt  | Menu Down  |  Down    |
| Auto/Track   |  Green   | Volume+    |  Vol +   |
| Slow Up      |  >>I   | Progr.     |  Sleep   |
| Rep/A-B      |  +  Shift + Text  | Next       |  Ch +    |
| Stop         |  Stop  | Volume-    |  Vol -   |
| Title        |  List  | Top Menu   |  D. Menu |
| Zoom         |  +  Shift + Eject | Prev.      |  Ch -    |
| Repeat/1/All |  Text   | 1          |  1      |
| Pause        |  Pause   | 2          |  2     |
| DVD/TV       |  AV  | 3          |  3     |
| Menu         |  Menu  | 4          |  4     |
| Menu Up      |  Up  | 5          |  5     |
| Display      |  Info  | 6          |  6     |
| Menu Left    |  Left  | 7          |  7     |



| Original    | Replacement  | Original | Replacement   |
|-------------|--|----------|---|
| 8           |  8        | Setup    |  Options |
| 9           |  9        | 3D       |  3D      |
| +10         |  Guide    |          |   |
| EQ          |  Media    |          |   |
| 0           |  0        |          |   |
| C/CH        |  Pre Ch   |          |   |
| Digest      |  Red      |          |   |
| Record      |  Rec      |          |   |
| Open/Close  |  Eject    |          |   |
| Mode        |  Smart    |          |   |
| Angle       |  TV/R    |          |   |
| Rewind      |  <<     |          |   |
| Play        |  Play   |          |   |
| Clear/00:00 |  Exit   |          |   |
| Audio       |  Dual   |          |   |
| F.Forward   |  >>     |          |   |
| NTSC/PAL    |  Format |          |   |

