



Original	Replacement
	 Power
	 Setup / OPT /
	 Sleep / Timer
	 Mute / Dimmer
	 Vol+
	 Vol-
	 AV / Input / RDS
	 CH+ / Page+
	 CH- / Page-
	 Picture / Format
	 TV/Radio /
	 Audio / Lang I/II
	 Display / Media
	 Smart / List
	 Menu / Home
	 Shift + TV/Radio / Program
	 Up

Original	Replacement
	 Down
	 Right
	 Left
	 OK
	 Fav / Marker / PC
	 Guide / EPG / -/-
	 Text / Goto
	 Info / Angle
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 1
	 2
	 3
	 4
	 5





	Original	Replacement	Original	Replacement
	6			
	7			
	8			
	9			
	0			
	-/--	+		
	Recall			

