
















































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Options	Menu Off	 Exit
Txt Stop	 Stop	Menu Down	 Down
Reveal	 List	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	
8		8
9		9
Guide -/-- 1.		Guide
0/10		0
2.Fav P/C 2.		Pre Ch
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue
Tone-		<<
Tone+		>>
Audio-		I<<
Audio+		>>I
Color+ P.Std	 + 	Shift + D. Menu
AV 2	 + 	Shift + AV
Browse	 + 	Shift + Back
Input	 + 	Shift + Vol +

Original	Replacement	
Output	 + 	Shift + Vol -
Nicam/Mono	 + 	Shift + Green
Color- S.Std	 + 	Shift + Dual
Level L	 + 	Shift + Yellow
Level R/Woofer	 + 	Shift + Blue

