













































Original	Replacement	Original	Replacement
	Power		Power
	VCR		Smart
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	Recall		Back
	Subtitle		Subt
	Auto		Media
	Info		Info
	Menu		Menu
	EPG		Guide
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue





	Original	Replacement	Original	Replacement
	Zoom	Eject		
	Lang/Audio	Dual		
	Play	Play		
	Pause	Pause		
	<<	<<		
	>>	>>		
	I<<	I<<		
	>>I	>>I		
	Text	Text		
	Tv/Radio	TV/R		

