



| Original | Replacement | Original | Replacement |
|--|---|---|--|
|  Power |  Power |  FAV- |  Shift + Ch - |
|  Mute |  Mute |  P.Mode |  Media |
|  1 |  1 |  S.Mode |  Options |
|  2 |  2 |  CH+ |  Ch + |
|  3 |  3 |  CH- |  Ch - |
|  4 |  4 |  Vol+ |  Vol + |
|  5 |  5 |  Vol- |  Vol - |
|  6 |  6 |  Input |  AV |
|  7 |  7 |  Sleep |  Sleep |
|  8 |  8 |  Aspect |  3D |
|  9 |  9 |  Info |  Info |
|  0 |  0 |  Menu |  Menu |
|  -/-- |  Shift + Guide |  Exit |  Exit |
|  Recall |  Back |  Up |  Up |
|  Audio |  Dual |  Down |  Down |
|  FAV |  Pre Ch |  Right |  Right |
|  FAV+ |  Shift + Ch + |  Left |  Left |





| Original | | Replacement | |
|----------|-------------|-------------|--------|
| | OK | | Ok |
| | Text | | Text |
| | Index | | Smart |
| | Play/Mix/T | | Play |
| | Pause | | Pause |
| | Stop/Reveal | | Stop |
| | <</Hold | | << |
| | >>/Subpage | | >> |
| | I<< | | I<< |
| | >>/Cancel | | >>I |
| | Rec | | Rec |
| | Size | | Format |
| | EPG | | Guide |
| | Tv/Radio | | TV/R |
| | Sub-T | | Subt |
| | Red | | Red |
| | Green | | Green |

| Original | | Replacement | |
|----------|--------|-------------|--------|
| | Yellow | | Yellow |
| | Blue | | Blue |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

