






































































































| Original | Replacement | Original | Replacement |
|---|--|--|--|
|  Power |  Power |  Up |  Up |
|  16:9 / Wide |  Picture / Format |  Left |  Left |
|  Mute |  Mute / Dimmer |  OK |  OK |
|  1 |  1 |  Right |  Right |
|  2 |  2 |  Down |  Down |
|  3 |  3 |  Vol + |  Vol+ |
|  4 |  4 |  Menu |  Menu / Home |
|  5 |  5 |  CH + |  CH+ / Page+ |
|  6 |  6 |  Vol - |  Vol- |
|  7 |  7 |  Source |  AV / Input / RDS |
|  8 |  8 |  CH - |  CH- / Page- |
|  9 |  9 |  Info |  Info / Angle |
|  0 |  0 |  Sleep |  Sleep / Timer |
|  F1 |  Exit / Cancel / Clear |  Recall |  Back / Return |
|  [:≡] |  D.Menu / Top |  L / R |  Eject / Surround |
|  Smart S |  Sound / Title |  Index / Play |  Play / Slow |
|  Smart P |  Shift + Picture / Format |  Index / Play |  Display / Media |

| Original | Replacement | Original | Replacement |
|--|--|--|--|
|  Up |  Up |  Up |  Up |
|  Left |  Left |  Left |  Left |
|  OK |  OK |  OK |  OK |
|  Right |  Right |  Right |  Right |
|  Down |  Down |  Down |  Down |
|  Vol + |  Vol+ |  Vol + |  Vol+ |
|  Menu |  Menu / Home |  Menu |  Menu / Home |
|  CH + |  CH+ / Page+ |  CH + |  CH+ / Page+ |
|  Vol - |  Vol- |  Vol - |  Vol- |
|  Source |  AV / Input / RDS |  SOURCE |  AV / Input / RDS |
|  CH - |  CH- / Page- |  CH - |  CH- / Page- |
|  Info |  Info / Angle |  INFO |  Info / Angle |
|  Sleep |  Sleep / Timer |  Sleep |  Sleep / Timer |
|  Recall |  Back / Return |  Recall |  Back / Return |
|  L / R |  Eject / Surround |  L/R |  Eject / Surround |
|  Index / Play |  Play / Slow |  INDEX |  SLOW |
|  Index / Play |  Display / Media |  INDEX |  MEDIA DISPLAY |



