







































































| Original | | Replacement | | Original | | Replacement | |
|---|-----------------|---|--------|---|--------|---|---------|
|  | Standby |  | Power |  | 9 |  | 9 |
|  | Open/Close |  | Eject |  | 0 |  | 0 |
|  | Angle |  | Format |  | Random |  | D. Menu |
|  | Info/Display |  | Info |  | Audio |  | Dual |
|  | Q-Play/Tv/Radio |  | TV/R |  | Vol+ |  | Vol + |
|  | PN/EPG |  | Guide |  | Vol- |  | Vol - |
|  | Search/TTX |  | Text |  | Stop |  | Stop |
|  | PBC/List |  | List |  | Play |  | Play |
|  | Subtitle |  | Subt |  | Pause |  | Pause |
|  | 1 |  | 1 |  | Prev |  | I<< |
|  | 2 |  | 2 |  | Red |  | Red |
|  | 3 |  | 3 |  | Green |  | Green |
|  | 4 |  | 4 |  | Yellow |  | Yellow |
|  | 5 |  | 5 |  | Blue |  | Blue |
|  | 6 |  | 6 |  | Next |  | >>I |
|  | 7 |  | 7 |  | Rew |  | << |
|  | 8 |  | 8 |  | FF |  | >> |





| Original | | Replacement | | Original | | Replacement | |
|---|-------------|---|---------------|----------|--|-------------|--|
|  | Setup |  | Options | | | | |
|  | Return |  | Back | | | | |
|  | Up/CH+ |  | Up | | | | |
|  | Down/CH- |  | Down | | | | |
|  | Right |  | Right | | | | |
|  | Left |  | Left | | | | |
|  | Enter |  | Ok | | | | |
|  | Title/Pg Up |  | Ch + | | | | |
|  | Menu/Pg Dn |  | Ch - | | | | |
|  | Zoom |  | Shift + Eject | | | | |
|  | Repeat |  | Shift + Text | | | | |
|  | FAV/A-B |  | Pre Ch | | | | |
|  | Exit/Slow |  | Exit | | | | |
|  | Video |  | AV | | | | |
|  | USB |  | Smart | | | | |
|  | DVD/DVB |  | Media | | | | |
|  | Mute |  | Mute | | | | |

