















































































| Original | Replacement |
|---|--|
|  Power |  Power |
|  Power Tv |  Shift + Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Txt |  Text / Goto |
|  0 |  0 |
|  [<>]/4:3/16:9 |  Picture / Format |
|  TV |  Subtitle / EQ |
|  Radio |  TV/Radio / |
|  Up |  Up |

| Original | Replacement |
|---|---|
|  Help |  Guide / EPG / -/-- |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Music |  Audio / Lang I/II |
|  Down |  Down |
|  WWW |  Display / Media |
|  Video |  Shift + 4 |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  Vol+ |  Vol+ |
|  Vol+ Tv |  Shift + Vol+ |
|  M |  Menu / Home |
|  Prog+ |  CH+ / Page+ |
|  Vol- |  Vol- |





| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------|
|  | Vol- Tv |  | Shift + Vol- |
|  | Back |  | Back / Return |
|  | Prog- |  | CH- / Page- |
|  | Mute |  | Mute / Dimmer |
|  | Mute Tv |  | Shift + Mute / Dimmer |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
|  | Stop |  | Stop / Hold |
|  | Buy |  | Fav / Marker / PC |
|  | I<< |  | I<< / Preset- |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |
|  | >>I |  | >>I / Preset+ |
| | | | |
| | | | |
| | | | |
| | | | |

