





































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Info	 +  Shift + Info	Menu Down	 Down
App	 Media	Back	 Back
Opt?	 Options	Audio	 Dual
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7



Original	Replacement	Original	Replacement
8tuv	 8	Scan/Setup	 Shift + TV/R
9wxyz	 9	SAT Sky	 Smart
Guide Pilote	 Guide		 Shift + Vol +
0/10	 0		 >>I
FAV Pref.	 Pre Ch		 Shift + Vol -
Red	 Red	Home Cinema	 Shift + Media
Green	 Green	East	 Shift + Red
Yellow	 Yellow		 I<<
Blue	 Blue	Lang./Rewind	 <<
Dev	 List	H/V Play	 Play
On/Off	 Shift + Power	LNB F.Forward	 >>
	 Shift + Mute		
West	 Shift + I<<		
+	 Shift + Subt		
Freeze	 Stop		
Dec/Pause	 Pause		
Sys/Serv	 Shift + Sleep		

