

































































| Original | Replacement | Original | Replacement |
|--|--|--|--|
|  Power |  Power |  Down |  Down |
|  Mute |  Mute |  Right |  Right |
|  1 |  1 |  Left |  Left |
|  2 |  2 |  OK |  Ok |
|  3 |  3 |  CH+ |  Ch + |
|  4 |  4 |  CH- |  Ch - |
|  5 |  5 |  Vol+ |  Vol + |
|  6 |  6 |  Vol- |  Vol - |
|  7 |  7 |  Sub-T. |  Subt |
|  8 |  8 |  Info |  Info |
|  9 |  9 |  Text |  Text |
|  0 |  0 |  Audio |  Dual |
|  Menu |  Menu |  USB |  AV |
|  Exit |  Exit |  Timer |  Shift + AV |
|  Last |  Pre Ch |  Favor |  Shift + Pre Ch |
|  Tv/R |  TV/R |  Red/I<< |  Red |
|  Up |  Up |  Green/<< |  Green |





| Original | Replacement | Original | Replacement |
|---|--|----------|-------------|
|  Yellow/>> |  Yellow | | |
|  Blue/>>I |  Blue | | |
|  Rec |  Rec | | |
|  Stop |  Stop | | |
|  Play |  Play | | |
|  Pause |  Pause | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

