







































































| Original   | Replacement  |
|--|--|
|  Power    |  Power                      |
|  Sleep    |  Sleep / Timer              |
|  Screen   |  Picture / Format           |
|  Presets  |  Setup / OPT /              |
|  ↔        |  TV/Radio /                 |
|  FAV      |  Shift + Fav / Marker / PC |
|  Lang     |  Audio / Lang I/II          |
|  Subtitle |  Subtitle / EQ              |
|  TXT      |  Text / Goto                |
|  1       |  1                         |
|  2      |  2                        |
|  3      |  3                        |
|  4      |  4                        |
|  5      |  5                        |
|  6      |  6                        |
|  7      |  7                        |
|  8      |  8                        |

| Original   | Replacement   |
|--|---|
|  9                |  9                         |
|  EPG              |  Guide / EPG / -/-         |
|  0                |  0                         |
|  SWAP             |  Fav / Marker / PC         |
|  Photo/Music/Movi |  D.Menu / Top              |
|  World            |  Smart / List              |
|  SOURCE           |  AV / Input / RDS          |
|  MENU             |  Menu / Home               |
|  Up               |  Up                        |
|  Left            |  Left                     |
|  OK             |  OK                      |
|  Right          |  Right                   |
|  Down           |  Down                    |
|  C              |  Exit / Cancel / Clear   |
|  DISP.          |  Display / Media         |
|  SEARCH MODE    |  Shift + Red / Netflix / |
|  RETURN         |  Back / Return           |





|  | Original       |  | Replacement            |  | Original    |  | Replacement                 |
|--|----------------|--|------------------------|--|-------------|--|-----------------------------|
|  | CH+            |  | CH+ / Page+            |  | Yellow/Root |  | Yellow / YouTube / Repeat   |
|  | Info           |  | Info / Angle           |  | Blue/Title  |  | Blue / Prime Video / Random |
|  | Vol+           |  | Vol+                   |  |             |  |                             |
|  | CH-            |  | CH- / Page-            |  |             |  |                             |
|  | Mute           |  | Mute / Dimmer          |  |             |  |                             |
|  | Vol-           |  | Vol-                   |  |             |  |                             |
|  | Rec            |  | Rec / Rec Mode         |  |             |  |                             |
|  | Pause          |  | Pause / Step / Freeze  |  |             |  |                             |
|  | I<<            |  | I<< / Preset-          |  |             |  |                             |
|  | >>I            |  | >>I / Preset+          |  |             |  |                             |
|  | <<             |  | << / Tune-             |  |             |  |                             |
|  | Play           |  | Play / Slow            |  |             |  |                             |
|  | Stop           |  | Stop / Hold            |  |             |  |                             |
|  | >>             |  | >> / Tune+             |  |             |  |                             |
|  | Red/↑/Zoom     |  | Red / Netflix / Search |  |             |  |                             |
|  | Red/↑/Zoom     |  | Zoom / Size            |  |             |  |                             |
|  | Green/↓/Repeat |  | Green / APP / Repeat   |  |             |  |                             |

