







































































Original		Replacement		Original		Replacement	
	Power		Power		EPG		Guide
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Info		Info
	8		8		Audio		Dual
	9		9		Zoom		Eject
	0		0		P+		Ch +
	AV		AV		P-		Ch -
	Tv/R		TV/R		Red		Red
	Menu		Menu		Green		Green
	Exit		Exit		Yellow		Yellow
	FAV		Pre Ch		Blue		Blue





Original		Replacement	
	SAT		Smart
	Text		Text
	Sub		Subt
	RCL		Options
	Pause		Pause
	<I		I<<
	I>		>>I
	Rec		Rec
	Play		Play
	<<		<<
	>>		>>
	Stop		Stop

Original		Replacement	

