



















| Original | Replacement |
|---|---|
|  Power |  Power |
|  Mute |  Mute |
|  PC |  Media |
|  Comp / HDMI |  Smart |
|  AV |  AV |
|  DTV / TV |  Shift + TV/R |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual |
|  Aspect |  Format |
|  Source |  Shift + AV |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |

| Original | Replacement |
|--|---|
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Still |  Pause |
|  Sleep |  Sleep |
|  Menu |  Menu |
|  Exit |  Exit |
|  Up |  Up |
|  Left |  Left |
|  OK |  Ok |
|  Right |  Right |
|  Down |  Down |
|  TTX |  Text |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  i / Status |  Info |
|  PR+ |  Ch + |





| Original | Replacement |
|--|--|
|  PR- |  Ch - |
|  PIP |  +  Shift + Red |
|  P.Source |  +  Shift + Green |
|  P.Size |  +  Shift + Yellow |
|  P.Sound |  +  Shift + Blue |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |
|  Index |  +  Shift + Info |
|  Cancel |  Back |
|  Hold |  Stop |
|  Subpage |  +  Shift + Subt |
|  Reveal |  List |
|  Mode |  +  Shift + Text |
|  Store |  3D |
|  TV / Radio |  TV/R |

| Original | Replacement |
|--|---|
|  Guide |  Guide |
|  Subtitle |  Subt |
|  I/II |  Dual |
|  Profile |  Pre Ch |
|  Audio |  Options |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

